

Congratulations on purchasing your Cocon storage system!



From now on you'll be able to safely store all your furniture and other things outdoors in this hermetically sealable plastic bag. You no longer have to worry about where to leave your furniture if you'll be doing a spot of DIY or renovating. Everything can be inside the Cocon on your own premises within half an hour. Talk about convenience!

You can use the Cocon to temporarily store your household goods for the purposes of:

- Sanding down your parquet flooring.
- Laying PVC, laminate or floor covering.
- Painting in the home.
- Renovation work.
- Fitting a new kitchen.

ESSENTIAL DETAILS

- The Cocon is 315 cm wide and has a diameter of 200 cm when optimally filled.
- The bag is sealed on three sides. For each metre in length you'll have 2.5 m³ of storage capacity at your disposal. A bag 6 metres long will suffice for: dining table, 6 chairs, 4 armchairs, two-seater and three-seater sofa, coffee table and 2 occasional tables. There will also be some space left for smaller items. In order to be able to tie the Cocon tight shut, you'll need between 100 and 150 cm of the length of the bag.
- The bag is made of extremely strong black-and-white polyethylene. Nevertheless, the sheet is not immune to developing holes. Please do therefore ensure that the surface on which you're using it is free of sharp objects. If you have cause to walk into the bag, please do so in socks or slippers to minimize the chances of damage. Before closing the bag, check whether there are any holes in it. This can be done by standing in the bag during daylight, closing the bag and searching for spots of light in the dark. If you see any, then check first whether these are genuine holes or if it's just that the bag has been stretched enough to let light shine through the sheet at that point. The Cocon comes with a roll of tape to cover up any small holes. It is important for you to do this, as if the bag is no longer watertight then your things could become moist and sustain water damage.
- If you seal the bag properly in line with the instructions, then it will not be possible for moisture to affect your valuable things. Do please bear in mind that condensation can form on the inside of the bag due to differences in outside temperature. The white exterior of the bag will combat temperature differences as much as possible. By covering your things with sheets whilst they're in the bag to ensure that the plastic doesn't come into contact with them, you'll be reducing the chances of condensation formation and damage to the plastic. We would advise occasionally opening the bag in dry weather for ventilation purposes.

TIPS

- Regularly check the Cocon for damage. Repair any holes or scratches using the tape supplied.
- Ensure that the things you put in the bag don't have any sharp edges that could cause damage.
- We would advise covering your things with an extra layer of sheets, cushions or plastic film. This will prevent your household goods from damaging the bag.
- Due to the lack of light once the bag is sealed, it's best not to store plants or flowers in it.

WARNING!

There is no light and very little oxygen in a sealed Cocon. Consequently, you should always ensure that there are no people or animals in the bag before closing the bag!

INSTRUCTIONS FOR USE

1. Inspect the surface on which you're using the bag and remove stones, twigs and other irregularities.
2. Remove the plastic bag from the box. Don't use scissors or a knife! This could cause irreparable damage to the bag.
3. Unfold the bag widthways.
4. Next, roll the bag out lengthways. The open side is on the exterior of the roll and the closed side is within the roll.
5. Plan what things you want to store where in the bag. Put tall furniture in the middle and lower furniture at the edges to make the most of the space.
6. As a minimum, work in pairs when filling the bag.
7. Put your items carefully in the bag.
8. The Cocon is lightproof, so use a torch or other lighting when filling it. Do take care when using hot sources of light such as construction lamps! If these touch the plastic it will melt.
9. Try to keep the bag as taut as possible when filling it to prevent the sheet from flapping in the wind.
10. As soon as all your items have been placed inside, close the end of the bag. Wind the supplied cord a few times around the sheet and seal it with a secure knot. Turn the wad of material downwards and fold it under the remainder of the sheet. This will prevent any water from getting into the sealing knot and keep your things dry.

REUSE

The Cocon is strong enough that it can be used more than once. If you're intending to reuse the bag, please only do so once you've confirmed that there is no damage to it.

The Cocon is best stored by folding it properly:

- 🌀 Lay the bag flat on an even surface.
- 🌀 Clean the Cocon and dry the surface.
- 🌀 Fold the bag a few times lengthways.
- 🌀 Then roll the sheet up, starting with the seam. This will enable all the air to escape from the bag and leave you with a handy package.
- 🌀 If you won't be reusing the Cocon, then you can also deposit it in the recycling bin for plastic waste.

For further information please see our website: www.coconshop.eu. You can also call: Flex-Pack B.V. – +31 (0)6-51 78 32 21 (Monday to Friday from 7 a.m. to 5 p.m.)

The Cocon is produced in the Netherlands by: